

### 产品特性

- 造型精致小巧, 方便随身携带, 专为军事、执法、探险 及户外狩猎所设计
- 采用CREE XP-L 或 Nichia 219C LED, 寿命长达
- 50000小时 • 最高输出950流明, 最远射程220米
- 数字恒流驱动电路, 续航最长可达80小时
- 第三代无极调光技术, 1-950流明无级亮度快速选择
- 隐藏爆闪及SOS功能
- 电池防反装保护 • 双面镀膜防刮光学镜片
- 航空级铝合金制造 • 不锈钢旋转控制环
- 三级硬质阳极氧化抗磨表面处理
- 尾部倒立设计
- IPX-8级防水(水下2米)
- 1米抗摔

### 产品参数

LED: CREE XP-L 或 Nichia 219C LED

最大输出: 950流明 反光杯: 精密光面反光杯

镜片: 钢化玻璃 筒身材质: 航空级铝合金

筒身处理: 军规三级硬质氧化军灰色表面耐磨处理

使用电池: 1\*CR123A/1\*RCR123A/1\*18350 开关: 无极磁环调光开关+尾部战术开关

长度: 81mm 头部直径: 25.7mm

尾部直径: 24.5mm 重量: 75.2克(不含电池)

## 选用电池

电池类型	尺寸规格	标称电压	是否可用
可充电锂离子电池	18350	3.7V	可用
可充电锂离子电池	RCR123A	3.7V	推荐
一次性锂电池	CR123A	3V	可用

### 亮度和时间

FL 1 STANDARD	最高亮 18350	最高亮 CR123	最低亮 CR123	爆闪 18350	SOS 18350
345	950流明	420流明	1流明	1 <del>-</del> 950 流明	1-950 流明
0	35分钟	1.5小时	80小时	1	1
	220米 (18350电池最远射程)				
	7200坎德拉 (18350电池最大光强)				
V	1米 (防跌落高度)				
~	IPX-8 (水下2米)				

免费赠送: O圈\*2、抱夹, 手绳、700mAh 16340带 USB充电锂电池




01

以上数据是按照国际电筒测量标准ANSI/NEMA, FL1所述之测量方法,使用一节JETBeam CR123(3V)锂 电池/18350 1100mAh(3.7V)可充电锂电池在实验室 内测量所得,不同电池或使用环境可能会对以上数据产

# 操作手电

### 装入电池

- 1. 打开尾盖, 从包装取出手电以及电池 2. 电池正极朝向手电头部(LED所在的一端)装入手电
- 3. 旋紧尾盖



02


- 1. 请将电池按照正极朝灯头方向放入, 反装电池电筒
- 将不能工作. 2. 不能将光线直接照射眼睛, 以免对眼睛造成伤害.

### 开启&关闭

- 1. 尾部战术开关ON/OFF手电 2. 当尾部开关开启时,逆时针旋转颈部控制环至关
- 闭,顺时针旋转颈部控制环开启手电

当电筒开启时, 旋转靠近电筒颈部的控制环, 电筒会改 变亮度,从1-950流明无级调光;如下图:关闭→1流明 (最低亮)→950流明(最高亮)→爆闪(快速旋转磁环2 次)→**SOS**(快速旋转磁环3次).

爆闪和SOS模式时,通过旋转磁环可以调节亮度,当磁 环旋转至关闭档位时,模式会被取消.



### 保养电筒

- 1. 长时间不用手电时请取出电池 2. 保存手电时请远离有火和潮湿环境
- 3. 请每半年使用软布清洁电筒的螺牙, 并使用硅润滑 油润滑螺牙, 另请经常清洁手电的导电接触面/接触点.

JETBEAM® 产品拥有售后保固服务. 在购买本产品的 15天内, 如果有任何质量问题均可向经销商要求免费更换. 在购买本产品的60个月内享受免费保固服务. 在 超过60个月免费保固期后,本产品享有终身有限度保 固服务, 如需要更换重要部件则需要收取成本费用.

### 本保固规则不适用于以下情况:

- 1. 人为破坏, 拆解, 改装本产品 2. 错误操作导致产品损坏(如装反电池等).
- 4. 盐水或海水腐蚀导致产品损坏

件到 info@jetbeamlight.com.

如需协助,JETBEAM® 敬请消费者首先联系购买产品 的经销商或零售商,以获得最迅速的售后服务或发邮

备注: 产品数据如有更新, 敬请以JETBEAM官方网站

### ★ 仅限国内区域,跨区销售将不给予保修。

# 深圳市杰特明电子科技有限公司

咨询热线: +86-0755-28077748 销售邮箱: info@jetbeamlight.com

网 址: www.jetbeamlight.com 公司地址: 广东省深圳市龙华新区大浪南路墩背工业区 一栋三楼 邮 编: 518109

05

05

# RŏHS F© C € 🏖 🗵

04



www.jetbeamlight.com

### Manual Thank you for choosing our products! www.jetbeamlight.com

- Exquisite and compact shape, easy to carry around, specially designed for military, law
- enforcement, exploring and outdoor hunting
   Adopt CREE XP-G3 or Nichia 219C LED, long lifespan up to 50000 hours
- Max output of 950 lumens and throw distance of 220 meters.
- · Adopt efficient digital constant current circuit, run
- time of max output up to 80 hours. The third generation of stepless dimming technology,
- choose the 1-950lumens desired light quickly.
- $\bullet\,$  Hidden strobe and SOS feature. . Battery reverse protection function . Toughened ultra-clear mineral glass with anti-
- reflective coating.
- Constructed from aero grade aluminum alloy. • Stainless steel revolve control ring.
- $\bullet\,$  Military grade HAIII hard-anodized finish. Tail Inverted Design
- Waterproof rating IPX8(underwater 2 meters). • 1 meter impact resistant.

# Specifications

LED: CREE XP-G3 or Nichia 219C+RGB LED Maximum output: 950 lumens Reflector cup: precision glossy reflector

Lens: tempered glass
Material: aviation-grade aluminum alloy Barrel treatment: Military grade three-level hard oxide army gray surface wear-resistant treatment Battery used: 1\* CR123A / 1\* RCR123A / 1\* 18350 Switch: Stepless magnetic ring dimming switch + Tail tactical switch Length: 81mm

### Battery for Use

•			
	Туре	Nominal Voltage	Compatibility
Rechargeable Lithium battery	18350	3.7V	Yes(recommended)
Rechargeable Lithium battery	RCR123A	3.7V	Yes(recommended)
Disposable	CB123A	3V	Yes

# **Output & Runtime**

output a realitimo					
FL1 STANDARD	Highest 18350	Highest CR123A	Lowest CR123A	Strobe 18350	SOS 18350
34.5	950LM	420LM	1LM	1-950LM	1-950LM
()	35min	1.5h	80h	/	/
	220m (Beam Distance in 18350 Battery)				
•	7200cd (Peak Beam Intensity in 18350 Battery)				
N.	1M (Impact Resistance)				
	IPX8 (Underwater 2 meter)				

Included for free: O ring\*2, clip, lanyard, 700mAh micro-USB rechargeable 16340 Li-ion battery




01

The above data is based on the international flashlight measurement standard ANSI / NEMA, The measurement method described in FL1 is measured in a laboratory using a JETBeam 18350 1100mAh (3.7V) rechargeable lithium battery. Different batteries or use environments may affect the above data.

# Operation of flashlight

- Insert the battery
- 1. Open the tail cover and remove the flashlight and battery from the package Insert the battery's positive pole towards the head of the flashlight (the end where the LED is
- 3. Tighten the end cap and insert the battery



# **Marning**

damage to the eyes.

02

- 1. Please put the battery in the direction of the positive pole toward the lamp head, and the battery flashlight will not work if it is reversed 2. Do not shine light directly on the eyes to avoid

- ON/OFF


  1. Tail tactical switch ON / OFF flashlight

  2. When the tail switch is turned on, turn the control ring counterclockwise to close
  Close, turn the control ring clockwise to turn on the flashlight
- the flashlight

03

Brightness and mode adjustment
When the flashlight is turned on, rotate the control ring the flashlight will change brightness output, stepless dimming from 1-950 lumens; as shown below: Off —1 lumens (Lowest light) — 950 lumens (highest light) — Strob (fast rotating magnetic ring 2 Times) — SOS (rapidly rotate the magnetic ring 3 times).

ring 3 times).
In Strob and SOS mode, the brightness can be adjusted by rotating the magnetic ring. When the magnetic ring is rotated to the closed position, the mode will be canceled.



### Light Maintenance 1. Take the battery out for storage if light will not be used for a long time

- 2. Keep the light away from heat, static electricity, and high humidity 3. Clean the thread and conductive contact of light
- with soft cloth. Lubricate the threads every 6 months

Warranty
We provide 60 months(5 years)of warranty period
for this product from the date of purchase in case
defects caused by material or workmanship with
normal use. Necessary material and labor cost will
be charged after this period

# Free warranty does not cover any damages or

1. This product is disassembled or modified by anyone other than an authorized JETBeam warranty 2. This product is damaged by using the wrong battery or incorrect usage. 3. This product is damaged by defective batteries (such as battery leak).

# 4. Salt water and corrosive damage to the unit. In need of warranty service, please contact your

local official JETBeam dealer
2. To contact JETBeam, please refer to below Email:info@jetbeamlight.com Phone:+86-0755-28077748
For the latest update, please visit www.jetbeamlight.com

Head diameter: 25.7mm Tail diameter: 24.5mm

Weight: 75.2g (without batteries)